



MICA CREEK PROCEDURE FOR
PLANT ISOLATED FOR PERMIT TO WORK
MCPS-HS&E-0008

Responsible Officer: PERMITS AND ISOLATIONS ENGINEER
SHIFT CHARGE ENGINEERS
TECHNICAL SERVICES OFFICERS

Approved : Title

Contents

1. Purpose
2. Scope
3. Actions
 - 3.1 Preparation of PTW and Plant Isolation Tag
 - 3.2 Information Required on Tag
 - 3.3 Use of Tag in Plant Isolation Process
 - 3.4 Removal of Tag in De-Isolation Process
4. Definitions
5. Reference Documentation
6. Attachments
7. Document History

1. Purpose

To ensure workers have safe access to plant through plant isolation under the MCPS Permit to Work System.

2. Scope

This procedure applies to all plant at Mica Creek Power Station.

3. Actions

3.1 Preparation of PTW and Plant Isolation Tag

When preparing the Permit to Work (PTW), the green PLANT ISOLATED FOR PERMIT TO WORK tag must be included wherever it is practical.

3.2 Information Required on Tag

Place the PTW number and date in the spaces provided on the tag.

3.3 Use of Tag in Plant Isolation Process

As part of the plant isolation process, place the green tag in a prominent position on the plant – preferably close to where the work will be carried out.

3.4 Removal of Tag in De-Isolation Process

As part of the de-isolation procedure, remove the green tag and discard it.

4. Definitions

None.

5. Reference Documentation

None.

6. Attachments

None.

7. Document History

Issue Date	Nature of Changes
	Original Issue